

# Ra-06 AT command manual

## AT Command Introduction

Version:	V1.2
Edition:	ZhongCheng/ZhangYan
Start Date:	2019-03-01
Audition:	Dong
Finish date:	2019-4-26



[深圳市安信可科技有限公司](#)  
[ShenZhen Ai-Thinker Technology Co., Ltd.](#)

Address: Room410, Building C, Huafeng Intelligence  
Innovation Port, Gushu, Xixiang, Baoan, Shenzhen China 518126  
Tel: 0755-29162996  
Web: <https://www.ai-thinker.com>

## Version

Version No.	Revised date	Edition	Modification description
V1.0	2019-3-1	ZC	Initial Version
V1.1	2019-3-1	ZC	
V1.3	2019-5-8	ZC	Increase rate rating comparision table

## Content

1. AT Command Grammar.....	4
2. AT command.....	4
2.1 Execution of orders.....	4
2.1.1 Query version information.....	4
2.1.2 Restart the system.....	5
2.1.3 Restoration of factory settings.....	5
2.1.4 Print all commands and help information.....	5
2.1.5 Query Device Unique Identification Number.....	5
2.2 System parameters.....	5
2.2.1 Equipment operation mode.....	5
2.2.2 Equipment commissioning grade.....	6
2.2.3 Serial port parameter setting.....	6
2.3 Lora Parameter Settings.....	7
2.3.1 Frequency setting.....	7
2.3.2 lora transmission rate.....	7
2.3.3 Local node address.....	7
2.3.4 Target node address.....	7
2.3.5 lora Transmission power.....	8
2.3.6 Lead code length.....	8
2.3.7 Spread spectrum factor SF frequency bandwidth BW coding rate setting.....	8
2.3.8 CAD Interval.....	8
2.3.9 Frequency jump cycle.....	9
2.3.10 Setting the frequency hopping list.....	9
2.3.11 Setting Network Number.....	9
2.4 Transmission and receiving command.....	9
2.4.1 Transmission data.....	9
2.4.2 Receiving data.....	10
2.5 Configure mode.....	10
2.5.1 Node join the gateway.....	10
2.5.2 Node joining the gateway operating mode.....	10
2.5.3 Node and Synchronization Gateway.....	10
2.5.4 Send data to gateway.....	11

# 1. AT Command Grammar

AT command uses the command line based on the ASCII code, command format refer to below:  
 Request message format: AT+<CMD>[OPTION][para, ...][\r][\n]. **Available to not add the newline characters(\r\n)!**

< > Must specify content

[ ] Options

Form 1 AT Request message format

Field	Description
AT+	Command message prefix
CMD	Command string
OPTION	Command operator. Can be following content: “=” : represents setting parameters. “?” : represents the current value of the query parameter. “” : represents an execution instruction “=? ”: represents the request instruction of help usage information
Para	Represents the setting parameter value
\r\n	Enter and Newline, ASCII respectively 0x0d,0x0A

Response message format: +OK\r\n (Command execution succeed)  
 +ERROR(-1)\r\n (command execution failed, , AT command error)  
 +ERROR(-2)\r\n (command execution failed AT command parameter error)

E.g:

1. Sets the local node address of the module: AT+ADDR=2018
2. Query module local node address : AT+ADDR?
3. Check the help : AT+ADDR=?

## 2. AT command

### 2.1 Execution of orders

#### 2.1.1 Query version information

Command	Possible return results	Note
---------	-------------------------	------

AT+VER	+OK and version information	
--------	-----------------------------	--

### 2.1.2 Restart the system

Command	Possible return results	Note
AT+RST	ID+SBC	Automatically save the setting parameters to the flash before restarting

### 2.1.3 Restoration of factory settings

Command	Possible return results	Note
AT+FAC	+OK	All user-setting parameters are permanently restored to factory settings and the system is restarted

### 2.1.4 Print all commands and help information

Command	Possible return results	Note
AT+HELP	+OK	

### 2.1.5 Query Device Unique Identification Number

Command	Possible return results	Note
AT+UUID	+OK and ID	ID can't change

## 2.2 System parameters

### 2.2.1 Equipment operation mode

Type	Command	Value range	Note
Setting command	AT+MODE=<Digital characters Value>	Value: 0: low power consumption operating 1: deep sleep	default low power consumption operating Wake up method
Query	AT+MODE?	2 : deep sleep+CAD receiving	under deep sleep:

command		detection ( waked up via wireless) Greater than 100: deep sleep value automatic wake-up in milliseconds	send any data to serial port.  To enter CAD receive detection mode, you need to set the CAD interval first, CMD:  AT+CSLT
---------	--	--	---

For example, set the device into deep sleep mode: AT+MODE=1。  
 AT+MODE=5000, Automatic wake-up after 5000 ms of deep sleep.

### 2.2.2 Equipment commissioning grade

Type	Command	Value range	Note
Setting command	AT+DBGL=<Digital characters Value>	Value:	
Query command	AT+DBGL?	0: Print only “+OK” 1: User mode, default 2: Debugging mode	

### 2.2.3 Serial port parameter setting

Type	Command	Value range	Note
Setting command	AT+UART=<Value1>,<Value2>,<Value3>	Baud rate Value1: 0~9 Parity check Value2: 1~2 Stop Value3: 0~2	The baud rate suggests not to select too small value 。 Greater than 9600bps
Query command	AT+UART?		

Parameter Description:

Buad rate Value1: range 0~9

- |              |               |
|--------------|---------------|
| 0: 2400 bps  | 5: 57600 bps  |
| 1: 4800 bps  | 6: 76800 bps  |
| 2: 9600 bps  | 7: 115200 bps |
| 3: 19200 bps | 8: 128000 bps |
| 4: 38400 bps | 9: 256000 bps |

Parity check Value2: range 1~2

- 1: Odd (Odd check)
- 2: Even (Dual checks)

Stop position Value3: range 0~3

- 0: 1

1: 1.5

2: 2

## 2.3 Lora Parameter Settings

### 2.3.1 Frequency setting

Type	Command	Value range	Note
Setting command	AT+FREQ=<Digital characters Value>	Value: 9 characters fixed in length, e.g: 470300000	Node devices with different frequencies can not communicate
Query command	AT+FREQ?		

### 2.3.2 lora transmission rate

Type	Command	Value range	Note
Setting command	AT+RATE=<Digital characters Value>	Value: 0~9	0~9,rate from low to high. Node devices at different rates can not communicate with each other
Query command	AT+RATE?		

Rate level	0	1	2	3	4	5	6	7	8	9
Corresponding rate(bps)	122	149	407	487	732	867	1302	2278	4557	9114

### 2.3.3 Local node address

Type	Command	Value range	Note
Setting command	AT+ADDR=<Digital characters Value>	Value: 1~65534	0: retain 65535: broadcast address
Query command	AT+ADDR?		

### 2.3.4 Target node address

Type	Command	Value range	Note
Setting command	AT+TADDR=<Digital characters Value>	Value: 1~65535	0: retain 65535 : broadcast address
Query	AT+TADDR?		

command			
---------	--	--	--

### 2.3.5 lora Transmission power

Type	Command	Value range	Note
Setting command	AT+POWER=<Digital characters Value>	Value: 2~20	
Query command	AT+POWER?		

### 2.3.6 Lead code length

Type	Command	Value range	Note
Setting command	AT+PRE=<Digital characters Value>	Value: 6~5000 Unit: Symbol	Default value: 8 Advise do not exceed 5000
Query command	AT+PRE?		

### 2.3.7 Spread spectrum factor SF frequency bandwidth BW coding rate setting

Type	Command	Value range	Note
Setting command	AT+SBC=<Digital characters Value1>,<Value2>,<Value3>	Spread spectrum factor Value1: 6~12	If the command and AT RATE are mutually exclusive, setting this parameter the former will invalidates , in contrast same argument.
Query command	AT+SBC?	Frequency bandwidth Value2: 0~9	
		Coding rate Value3: 1~4	

Spread spectrum factor: 6: 64, 7: 128, 8: 256, 9: 512, 10: 1024, 11: 2048, 12: 4096 chips

Frequency bandwidth: 0: 7.8kHz, 1: 10.4 kHz, 2: 15.6 kHz, 3: 20.8 kHz, 4: 31.2 kHz,

5: 41.6 kHz, 6: 62.5 kHz, 7: 125 kHz, 8: 250 kHz, 9: 500 kHz。

Coding rate: 1: 4/5 2: 4/6 3: 4/7 4: 4/8

E.g: AT+SBC=7,7,2

### 2.3.8 CAD Interval

Type	Command	Value range	Note
Setting command	AT+CSLT=<Digital characters Value>	Value: 100~ 5000 Unit: ms	Enter CAD receive detection to set this parameter first.
Query command	AT+CSLT?		Default value 200.



### 2.3.9 Frequency jump cycle

Type	Command	Value range	Note
Setting command	AT+FHSS=<Value>	Value: 0~255	Recommend greater30
Query command	AT+FHSS?	0 : Closed frequency hopping, default	

### 2.3.10 Setting the frequency hopping list

Type	Command	Value range	Note
Setting command	AT+CH=<Value1>,<Value2>	Value1: Set Network Number	Frequency hopping by number
Query command	AT+CH?	Value2: Frequency value, Unit: Hz	

E.g: AT+CH=0,475000000  
 AT+CH=1,475100000  
 AT+CH=2,475300000

### 2.3.11 Setting Network Number

Type	Command	Value range	Note
Setting command	AT+NETID=<Value>	Value: 1~254 Default value: 90	Modules with different network numbers can not communicate with each other
Query command	AT+NETID?		

## 2.4 Transmission and receiving command

### 2.4.1 Transmission data

Type	Command	Value range	Note
Setting command	AT+MSG=<Value>	ASCII Characters or binary data	For nodes communication, receive reply message after ACKMSG send
	AT+ACKMSG=<Value> (reponse)		

Query command	No		
---------------	----	--	--

## 2.4.2 Receiving data

Type	Command	Value range	Note
Setting command	AT+RECV=<Digital characters Value>	Value: 0: Closed reception	CAD interval must be set before entering CAD detection mode (AT+CSLT)
Query command	AT+RECV?	1: Receiving data 2: Enable CAD detection and receive	

## 2.5 Configure mode

First set the node to working mode, then join the gateway, if it is Plan B mode, join the gateway to synchronize the gateway.

### 2.5.1 Node join the gateway

Command	Possible return results	Note
AT+JOIN	+OK	Gets the gateway assigned address and communication frequency

### 2.5.2 Node joining the gateway operating mode

Type	Command	Value range	Note
Setting command	AT+PLAN=<Value>	Value: A,B,C	Plan A: Open reception only after sending data Plan B: Set specific time to receive Plan C: Continue to receive
Query command	AT+PLAN?		

### 2.5.3 Node and Synchronization Gateway

Type	Command	Value range	Note
Setting command	AT+SYNC=<Value>	Value: 0: Cancel	Request at Plan B mode

Query command	N/A	1: Synchronization	
---------------	-----	--------------------	--

#### 2.5.4 Send data to gateway

Type	Command	Data range	Note
Setting command	AT+NETMSG=<Data>		Send message from node to gateway
Query command	N/A		